

Evaluation of Spray Nozzles for Aerial Application of Biological Control Agents




Yanbo Huang, USDA ARS
Steven J. Thomson, USDA NIFA



Evaluation of Aerial Application Systems to Release Liquid Formations

- Nozzle/atomizer setups
- *Adjuvant mixes*
- Weather conditions
- Spray release heights




Field and model studies



Quick Evaluations of


- In-swath deposition
- Off-target drift
- Canopy penetration



Nozzles of Aerial Application Systems



Davidon



CP




Accuflo




Micronair

CP-11TT Flat-Fan Nozzles Field Tests




In-Swath Deposition



Downwind Drift

Assessing Crop Injury Caused by Off-Target Drift of Aerially Applied Glyphosate





Davidon Tri-Set Nozzles In-Swath Deposition Test


- **Tank Mix:** Water, DRP-955 @35psi with 0.5 oz/gal
- 60 nozzles total (30 on each boom left and right)
- **Spray swath:** 65 ft **Flight Speed:** 135 mph
Spray altitude: 12 ft **Pressure:** 35 psi
- **WSP:** -32.5 ft, -21.67 ft, -10.83 ft, 0 ft, 10.83 ft, 21.67 ft, 32.5 ft (Number of Samples: 7 sampling stations x 3 nozzle deflections x 3 nozzle orifices x 4 reps = 252)
- **Kestrel 4500:** Wind speed, wind direction, air temperature, and relative humidity



Deflection	Orifice	Reps	Run	Label Head
0 degree	Small	1-4	1	OS1-1, OS4-1, OS3-1, OS4-1
	Medium	1-4	2	OM1-2, OM2-2, OM3-2, OM4-2
	Large	1-4	3	OL1-3, OL2-3, OL3-3, OL4-3
22.5 degree	Small	1-4	4	22S1-4, 22S2-4, 22S3-4, 22S4-4
	Medium	1-4	5	22M1-5, 22M2-5, 22M3-5, 22M4-5
	Large	1-4	6	22L1-6, 22L2-6, 22L3-6, 22L4-6
45 degree	Small	1-4	7	45S1-7, 45S2-7, 45S3-7, 45S4-7
	Medium	1-4	8	45M1-8, 45M2-8, 45M3-8, 45M4-8
	Large	1-4	9	45L1-9, 45L2-9, 45L3-9, 45L4-9




0 degree, Small Orifice




DV0.1 DV0.5 DV0.9 RS

0 Degree, Medium Orifice




DV0.1 DV0.5 DV0.9 RS

0 Degree, Large Orifice




DV0.1 DV0.5 DV0.9 RS


22 Degree, Small Orifice




22 Degree, Medium Orifice




22 Degree, Large Orifice




45 Degree, Small Orifice





45 Degree, Medium Orifice




45 Degree, Large Orifice





- 0 degree, small orifice
- 0 degree, medium orifice
- 0 degree, large orifice
- 22 degree, small orifice
- 22 degree, medium orifice
- 22 degree, large orifice
- 45 degree, small orifice
- 45 degree, medium orifice
- 45 degree, large orifice

- 0 degree, small orifice
- 0 degree, medium orifice
- 0 degree, large orifice
- 22 degree, small orifice
- 22 degree, medium orifice
- 22 degree, large orifice
- 45 degree, small orifice
- 45 degree, medium orifice
- 45 degree, large orifice



- 0 degree, small orifice
- 0 degree, medium orifice
- 0 degree, large orifice
- 22 degree, small orifice
- 22 degree, medium orifice
- 22 degree, large orifice
- 45 degree, small orifice
- 45 degree, medium orifice
- 45 degree, large orifice



Developing Aerial Systems to Effectively Deliver Liquid Formulations of Non-Toxigenic Biological Agents to Control Mycotoxins in Corn


- Aflatoxin, a poisonous by product produced by the fungi *Aspergillus flavus* and *A. parasiticus*, negatively impacts marketing and utilization of corn
- Release of non-toxigenic *A. flavus* into corn fields has shown promise as a biological control agent for aflatoxin producing strains of the fungus
- In corn production systems, many producers use Afla-Guard[®], a commercially available product containing non-toxigenic *A. flavus* as a biological control agent with crop consultants' recommend applying it between the V10-V12 growth stages

- For aerial application, there are obstacles that impede the adoption of Afla-Guard® and related products
- The application of a coarse granule to mature, 2 meter-tall corn is a challenge. Aerial applicators are often in high demand and applicators are not commonly prepared at that time to handle granular materials, particularly at the low use rates labeled for Afla-Guard®. Thus, there would be substantial advantages to a liquid formulation



- Water dispersible granule (WDG) formulations have several advantages over wettable powder, emulsifiable, oil or granular formulations. The development of WDG does not need solvents, and WDG formulations can greatly reduce the dust generated during application. Moreover, WDG has less long-term residual impact on our environment than oil or emulsifiable formulations
- The development of WDG formulations has been increased in recent years (Jin et al., 2008 & 2009)

- Application efficacy from aerial platforms has been studied extensively
- However, more information is needed on the ability of aerial delivery systems to effectively apply biological agents, especially new specialized mixtures such as those described by Jin et al. (2013)
- One nozzle that could be considered for this application is the Accu-Flo™ nozzle (Bishop Equipment Mfg., Hatfield, PA). This nozzle finds extensive use in Forestry applications and was found to penetrate spray most effectively into soybean canopies (Thomson et al., 2007). It is unique in that it does not use pressure to shatter the spray into small droplets, and this non-shattering characteristic might also have significant advantages when applying relatively delicate biological products.





Thanks!